Deutsche Sauna-Akademie®	**Deutsche Sauna-Akademie**
Titel	How Powerful Should a Sauna Heater Be?
Subtitel	Room volume, heat losses, glass surfaces, stone mass, warm-up time, control behaviour and technical sizing
Author	Dr. Karsten Gröning
Published by	International Sauna Academy | Sauna Library

Short answer: A sauna heater should be sized to the effective thermal load of the cabin, not simply to the number of seats or the desired maximum temperature. For a well-insulated timber-lined sauna, approximately 1 kW per cubic metre is a common manufacturer starting point. Glass, stone, tile, concrete and other poorly insulated or heat-storing surfaces increase the effective room volume; Harvia, for example, adds 1.2 m³ for each square metre of such surface, while uninsulated log construction is treated with a factor of 1.5. These coefficients are manufacturer-specific sizing rules, not universal laws. Stone mass, heater construction, ventilation, room geometry, ambient conditions and control strategy then determine warm-up behaviour and the character of Aufguss. The correct heater is therefore not the largest unit that fits electrically. It is the model whose approved room-volume range matches the calculated cabin under its actual construction conditions.

Heater power is one of the most frequently simplified questions in sauna construction. A room has a certain volume, a rule of thumb is applied, and a kilowatt value appears. That is useful as a first estimate—but it is not yet a technical design.

A heater must first warm the cabin, its surfaces and its stone mass. It must then compensate continuously for transmission losses, ventilation losses, door opening and the temporary energy demand associated with Aufguss. Its control system must do this without producing excessive cycling, inadequate stone temperature or an unnecessarily aggressive thermal environment.

> **Heater sizing is a heat-load problem, not a temperature-setting problem.**

Start with the actual room volume

The geometric starting point is simple: internal length × width × height gives the sauna volume in cubic metres.

For a well-insulated, timber-lined cabin, manufacturers commonly use approximately 1 kW of nominal heater power per cubic metre as an initial sizing rule. Harvia currently states this explicitly as an average requirement [1].

This is a selection rule, not a physical constant. The next step is to ask whether the measured cubic volume actually represents the thermal load.

Why physical volume is not enough

Two cabins with exactly the same internal dimensions can require different heater capacities. One may have insulated timber walls and a small insulated door; the other may have a full glass front, tiled wall and exposed masonry.

The second cabin loses heat more readily and must also heat more thermally massive surfaces. From the heater's perspective it behaves like a larger room.

Manufacturers therefore use an 'effective' or corrected sauna volume when selecting a heater.

How glass changes the calculation

Glass is visually attractive but thermally very different from a well-insulated timber wall. It provides little insulation compared with a properly constructed sauna envelope and creates additional heat loss.

Harvia's current European guidance treats each square metre of glass, stone or similar uninsulated surface as the equivalent of adding 1.2 m^3 to the room volume [1].

A sauna measuring 8.0 m^3 with 3.0 m^2 of such surface would therefore be treated, under this particular rule, as approximately 11.6 m^3 before heater selection.

> **The cabin does not become physically larger. It becomes thermally larger.**

Why the correction factor is not universal

The 1.2 m^3-per-square-metre value is a manufacturer's sizing convention. Other heater manufacturers may use different coefficients, different volume ranges or different definitions of cold surface.

The correct procedure is therefore to calculate according to the sizing method of the heater actually being installed and then select a model whose approved room range contains that corrected value.

A generic internet calculator should never overrule the installation manual of the chosen heater.

What about an ordinary glass door?

A glass door contributes to the thermal load for the same reason as a glass wall. Harvia gives the example that a nominal 10 m^3 sauna with a glass door behaves approximately like a 12 m^3 room for heater selection [2].

The exact adjustment depends on the manufacturer's method and the area involved. A large frameless glass front can alter the calculation much more strongly than a modest door.

Modern visual design can therefore have a very real electrical and thermal cost.

What about stone, tile and concrete?

Exposed stone, brick, tile and concrete can absorb substantial heat and, when not backed by an effective sauna insulation system, increase heat loss.

Harvia groups stone, glass and similar uninsulated surfaces together in its current sizing guidance, adding 1.2 m^3 of effective volume per square metre [1].

The practical message is not that all these materials are thermally identical. It is that exposed non-insulated surfaces must be included in the heater calculation.

Why log saunas are treated differently

Massive log walls store considerable heat and are not equivalent to a lightweight insulated timber-panel construction.

Harvia's sizing guidance uses a factor of 1.5 when the sauna's interior walls are made from uninsulated logs [1]. A geometrically 10 m³ log sauna would therefore be treated as approximately 15 m³ under that rule.

Again, this is a manufacturer-specific selection method rather than a universal thermodynamic coefficient.

What does insulation change?

Insulation reduces the rate at which heat flows through walls and ceiling to the surrounding building or outdoor environment. The ceiling is especially important because the hottest cabin air and surfaces are located high in the room.

Good insulation therefore reduces the continuous power needed to maintain the desired thermal state after warm-up.

Poor insulation cannot be fully 'fixed' by installing a larger heater. The heater may reach temperature, but energy consumption, surface gradients and control behaviour can remain poor.

What power actually means

A 9 kW electric heater can convert electrical energy into heat at a maximum rate of approximately 9 kJ per second while its elements are energised. Power is therefore a rate of energy delivery.

It does not tell us how much energy the heater stones can store, how quickly the cabin surfaces warm, how the heat is distributed or how the heater behaves during Aufguss.

Two heaters with the same nominal kW rating can consequently produce different practical sauna behaviour.

Why stone mass matters

Sauna stones act as a thermal reservoir and as the hot surface on which Aufguss water is evaporated. Heating a larger stone mass requires more energy before the sauna is fully ready.

Harvia itself distinguishes heater experiences partly by stone quantity: pillar heaters with large stone masses generally take longer to heat but can produce a softer, more persistent löyly [3].

Stone mass therefore affects thermal inertia and Aufguss behaviour, but it does not replace correct heater power.

> **Kilowatts determine how fast energy can be supplied. Stone mass influences how much thermal energy can be stored.**

A simple energy example

Suppose a heater contains 80 kg of stone. If the average specific heat capacity is roughly 0.8 kJ/(kg·K), raising the stone mass by 250 K requires on the order of 16 MJ of sensible heat.

A 9 kW heater could theoretically supply 16 MJ in about 30 minutes if every joule went only into the stones. In reality, energy simultaneously heats the heater structure, air, timber, glass and other surfaces while heat is already being lost through ventilation and the envelope.

This illustrates why warm-up time cannot be predicted from heater kW and room volume alone.

Why more stones can mean slower warm-up

A large stone mass has greater thermal capacity. More energy must be stored before the stones reach an effective Aufguss temperature.

This can lengthen warm-up, particularly in open pillar designs where a large stone surface also exchanges heat continuously with the room.

The benefit is thermal reserve: once hot, the stones can absorb water and support repeated evaporation with less abrupt surface cooling.

Why too few hot stones can be a problem

A heater may be powerful enough to make the cabin air hot while its stone bed is not optimally prepared for repeated Aufguss.

When water is applied, energy is consumed in heating and vaporising that water. If the stone surface cools too far, subsequent water may evaporate more slowly or pass deeper through the heater.

Good Aufguss performance therefore depends on both electrical power and a sufficiently hot, correctly arranged stone mass.

Does a bigger heater always heat faster?

Within limits, greater available power can shorten warm-up because energy can be delivered more rapidly. But the heater must be approved for the room volume and installed according to its safety distances and electrical requirements.

Warm-up is also limited by the thermal mass of the room, stone quantity, control sensor and heat losses. A heater that reaches its control temperature quickly may still have stones or surfaces that have not reached a stable thermal state.

The first thermostat cut-off is therefore not necessarily the same thing as 'sauna fully ready'.

What is warm-up time?

Warm-up time can mean several different things: time until the control sensor reaches its setpoint, time until the upper bench reaches a desired air temperature, time until surfaces approach thermal equilibrium, or time until the stone bed is ready for the intended Aufguss.

These endpoints are not identical.

Technical comparisons should therefore state what 'heated up' actually means rather than presenting a single minute value as a property of the heater alone.

Why room geometry matters

A tall sauna has more volume, but geometry also determines how much hot air accumulates above the occupied zone. Poor bench placement can leave bathers below the hottest layer.

A larger heater cannot correct fundamentally poor room proportions. It may simply create an even hotter unused ceiling zone.

Heater sizing should therefore be coordinated with ceiling height, bench position and ventilation.

What role does ventilation play?

Ventilation continuously removes warm cabin air and replaces it with cooler supply air. This is an intentional heat loss and must be covered by the heater.

Increasing ventilation flow increases the sensible heat needed to raise incoming air to cabin temperature. During Aufguss, exhaust air also carries water vapour and its associated enthalpy out of the room.

Ventilation is therefore part of the design load, but it should never be reduced below an appropriate level merely to compensate for an undersized heater.

A simple ventilation heat calculation

For dry air, the sensible ventilation load can be estimated from air mass flow × specific heat capacity × temperature difference.

For example, heating 100 m^3/h of incoming air from 20 °C to 90 °C requires roughly 2.3 kW of sensible heat before humidity effects and other losses are considered.

This does not mean a sauna needs an extra 2.3 kW heater in every such case; it shows why ventilation rate materially influences the steady-state heat balance.

What happens when the door opens?

Door opening creates a short, large disturbance. Hot air escapes from the upper cabin while cooler surrounding air enters, often near floor level.

The heater then has to restore both air temperature and the disturbed thermal circulation. Frequent door opening in a commercial sauna therefore creates a different load from occasional entry in a private cabin.

Nominal room volume alone cannot describe this operational difference.

What happens during Aufguss?

Water placed on hot stones must first be heated and then vaporised. The latent heat of vaporisation is large, so every Aufguss withdraws thermal energy from the stones.

A well-heated stone bed acts as a buffer. Its temperature falls locally as water evaporates and then recovers as the heating elements transfer more energy into the stones.

Repeated large Aufgüsse therefore test thermal reserve and recovery behaviour, not merely cabin-air temperature.

Why heater power and Aufguss water are not interchangeable

Installing a more powerful heater does not justify unlimited water application. The heater manufacturer specifies how water may be applied and the stones must remain capable of evaporating it safely.

Conversely, a large stone mass does not mean the cabin requires less electrical power. Stored heat must first be supplied by the heater.

Power, stone mass and water quantity are three different variables that interact.

What does an undersized heater do?

An undersized heater takes longer to warm the cabin and may spend very long periods at full output. Harvia explicitly notes that insufficient heater capacity requires longer and more intensive heating and can shorten heater life [1].

Recovery after door opening or Aufguss can be slow, and the desired temperature may become difficult to maintain under high occupancy or cold ambient conditions.

The result is not necessarily a gentler sauna. It can simply be an unstable and inefficient one.

Can a heater be oversized?

Yes. More power is not automatically better. A heater far above the manufacturer's intended room range can raise air temperature very quickly and produce undesirable control cycling before the cabin and stone mass have developed the intended thermal state.

The exact behaviour depends on heater design, sensor position and controller logic, which is why the manufacturer's minimum and maximum room-volume limits matter.

The goal is appropriate capacity with useful reserve—not maximum installed kW.

> **An undersized heater struggles. An oversized heater can outrun the thermal system.**

What is control cycling?

Electric heaters normally regulate temperature by switching heating elements on and off in response to a sensor and controller. Once the measured temperature reaches the control threshold, some or all heating power is interrupted.

The cabin then cools until the controller calls for heat again. The frequency and duration of these cycles depend on heater power, room heat loss, thermal mass, sensor position and controller hysteresis.

A well-matched system maintains a stable useful thermal environment without extreme short cycling or near-continuous full-power operation.

Why sensor position matters

The controller only knows the temperature where its sensor is located. A sensor positioned in a particularly hot airflow can switch the heater off while the rest of the cabin remains relatively cool.

Conversely, an incorrectly positioned sensor may allow excessive heating.

Manufacturer instructions for sensor placement are therefore part of heater sizing and control design, not a cosmetic installation detail.

Why a sauna can be hot but the stones too cool

Air has a low thermal mass compared with dozens of kilograms of stone. A powerful heater can therefore raise air temperature relatively quickly while the stone bed is still accumulating energy.

If the controller then reduces element operation because the air sensor has reached setpoint, stone heating may proceed differently from what a simple room-temperature reading suggests.

Heater architecture is designed around this interaction, which is another reason not to compare heaters solely by kW.

Open versus enclosed stone systems

Open pillar heaters expose a large stone surface directly to cabin air. They can provide abundant contact area for water and a characteristic softer löyly, but large stone masses generally increase thermal inertia.

More enclosed heaters may heat the room and a smaller stone charge differently. Some designs deliberately separate air heating from stone heating or use additional control strategies.

There is therefore no universal statement that one kW rating corresponds to one identical sauna experience.

Does a more powerful heater use more electricity?

A higher-rated heater draws more electrical power while its elements are energised, but energy consumption over a complete session also depends on how long it runs.

A correctly sized higher-power heater may reach operating conditions sooner and then cycle, while an undersized unit may remain energised for much longer.

Energy use is determined by the total heat required by the cabin plus system losses—not simply by the number printed on the heater.

Why heat loss ultimately controls steady-state demand

During warm-up, heater power must both increase stored thermal energy and cover ongoing losses. Once the cabin approaches a stable state, the average required power increasingly reflects heat losses through walls, ceiling, glass, ventilation and door use.

This distinction explains why thermal mass strongly affects warm-up time but insulation and ventilation dominate long-term maintenance demand.

The heater must be able to satisfy both phases.

What about outdoor saunas?

Outdoor saunas face larger and more variable temperature differences across the building envelope. Wind, low outdoor temperatures, floor construction and exposed glazing can all increase heat loss.

A manufacturer-approved heater range must therefore be interpreted together with the actual construction. The same internal room volume can behave very differently in a heated building and in a freestanding winter sauna.

Good insulation and airtight construction become particularly important outdoors.

What about commercial saunas?

Commercial cabins often experience frequent door opening, high occupancy, repeated Aufguss and long daily operating periods. Their thermal duty cycle is therefore different from that of a private sauna used for one or two rounds.

Technical design should consider recovery behaviour, controls, electrical infrastructure, ventilation and serviceability in addition to nominal room volume.

Simply scaling a domestic rule of thumb upward is not always sufficient.

How should the heater actually be selected?

First calculate the internal cabin volume. Second identify all glass, masonry, tile, concrete, log construction and other surfaces that require correction under the chosen manufacturer's method.

Third calculate the manufacturer's effective room volume and identify heater models whose specified operating range contains that value. Fourth consider stone mass, intended Aufguss practice, ventilation, usage pattern, electrical supply, controller and required safety distances.

Finally, follow the heater's installation instructions and applicable electrical and fire-safety requirements.

> **Calculate the room. Correct the thermal load. Then select from the manufacturer's approved range.**

A worked example

Consider a well-insulated sauna 2.0 m wide, 2.0 m deep and 2.1 m high. Its physical volume is 8.4 m^3.

Now add a 3.0 m^2 glass front. Using Harvia's current European correction of 1.2 m^3 per square metre, the glass contributes 3.6 m^3 of effective volume. The corrected volume becomes 12.0 m^3 [1].

The next step is not to declare that the sauna 'needs exactly 12 kW'. It is to consult the selected heater family's approved room-volume ranges and choose the appropriate model. Another manufacturer's calculation may differ.

Why the 1 kW/m^3 rule should not become dogma

The rule is useful because it rapidly identifies the correct order of magnitude for a conventional insulated sauna. It becomes misleading when treated as a physical law.

A heater is not heating cubic metres in isolation. It is heating air, stones, surfaces and occupants while compensating for transmission, ventilation and operational losses.

The corrected-volume method is therefore a practical engineering shortcut for a more complicated heat-balance problem.

What should not determine heater size?

The number of bathers alone does not determine heater kW. Neither does a wish for 'very hot sauna', a large quantity of Aufguss water, or the assumption that more powerful equipment is more professional.

Likewise, a heater should not be selected merely because it physically fits the available wall space.

Thermal load, manufacturer limits, electrical installation and safe clearances must determine the technical choice.

What is the most common planning error?

One common error is calculating only length × width × height and ignoring glass. Modern cabins often contain precisely the large transparent surfaces that most strongly change the corrected volume.

Another is using a rule from one manufacturer to size a heater from another. The coefficients and approved volume ranges are part of the heater system.

A third is assuming that a bigger heater will compensate for poor insulation, excessive room height or bad ventilation design.

So, how powerful should a sauna heater be?

Power should be sufficient to heat the effective cabin volume within the intended operating pattern and to recover from normal heat losses, without exceeding the manufacturer's approved room range.

For a conventional insulated timber sauna, approximately 1 kW/m³ is a useful first orientation. Glass and other uninsulated surfaces then require correction; under Harvia's current method, each square metre adds 1.2 m³, while uninsulated log construction uses a 1.5 factor [1].

Stone mass, ventilation, warm-up expectations, control behaviour and Aufguss requirements then refine the technical choice.

Conclusion

Sauna-heater sizing is best understood as a thermal-system problem. Room volume establishes the starting load; glass, masonry and construction quality modify it; ventilation and door use create ongoing losses; stone mass determines thermal inertia; and the controller determines how available power is delivered over time.

The correct heater is therefore neither the smallest unit that can eventually reach the set temperature nor the largest unit the electrical supply can support.

It is a heater matched to the corrected room load and used within the manufacturer's specified range, with enough thermal reserve for the intended sauna operation.

Good sauna engineering does not ask, 'How many kilowatts can we install?' It asks, 'How much controlled heat does this particular cabin actually require?'

References

1. Harvia. How do I select the correct heater power? Technical support guidance, updated 2026. Manufacturer sizing rule: approximately 1 kW/m³; +1.2 m³ per m² of glass, stone or similar uninsulated surface; factor 1.5 for uninsulated log walls.

2. Harvia. Sauna heater installation and operating instructions. Heater-power section: corrected sauna volume for uninsulated brick, glass, concrete and tile surfaces; examples for glass doors and massive-log construction.

3. Harvia. Sauna product and design guidance. Heater selection and stone-mass characteristics; large stone masses generally require longer warm-up and support a gentler, longer-lasting löyly.

4. Incropera FP, DeWitt DP, Bergman TL, Lavine AS. Fundamentals of Heat and Mass Transfer. Principles of transient heating, thermal storage, convection and building-envelope heat transfer.

5. Helamaa E, Aikäs E. The secret of good löyly. Annals of Clinical Research. 1988;20(4):224–229. PMID: 3218892.

6. Äikäs E, Holmberg R. Saunan lämpötilat ja ilmanvaihto [Temperature and ventilation of the Finnish sauna]. VTT Tiedotteita – Research Notes 1431. Espoo: VTT Technical Research Centre of Finland; 1992.

7. Gröning K. Qualitätsorientierter Saunabau. Deutsche Sauna-Akademie / International Sauna Academy. Design framework for room geometry, insulation, ventilation, heater selection and bench arrangement.

8. Gröning K. Health-Orientated Sauna Bathing. International Sauna Academy, 2026. Sections on sauna climate, heat transfer, Aufguss and thermal dose.

Editorial note: Heater-sizing coefficients are manufacturer-specific selection rules. Always use the current technical documentation for the exact heater model and comply with local electrical, fire-safety and installation requirements.